DIAGNOSTIC TROUBLE CODE CHART

COMMUNICATION DIAGNOSIS:

DTC No.	Detection Item	Trouble Area	See page
01-21	ROM Error	Radio receiver	AV-31
01-22	RAM Error	Radio receiver	AV-31
01-D5	Absence of Registration Unit	1. Power source circuit of the component shown by the sub-code 2. AVC-LAN circuit between the radio receiver and the component shown by the sub-code 3. Component shown by the sub-code	AV-32
01-D6	No Master	1. Radio receiver power source circuit 2. Power source circuit of the component which has stored this code 3. AVC-LAN circuit between the radio receiver and the component which has stored this code 4. Component which has stored this code 5. Radio receiver	AV-34
01-D7	Connection Check Error	1. Radio receiver power source circuit 2. Power source circuit of the component which has stored this code 3. AVC-LAN circuit between the radio receiver and the component which has stored this code 4. Component which has stored this code 5. Radio receiver	AV-34
01-D8	No Response for Connection Check	1. Power source circuit of the component shown by the sub-code 2. AVC-LAN circuit between the radio receiver and the component shown by the sub-code 3. Component shown by the sub-code	AV-32
01-D9	Last Mode Error	1. Power source circuit of the component shown by the sub-code 2. AVC-LAN circuit between the radio receiver and the component shown by the sub-code 3. Component shown by the sub-code	AV-32
01-DA	No Response Against ON / OFF Command	1. Power source circuit of the component shown by the sub-code 2. AVC-LAN circuit between the radio receiver and the component shown by the sub-code 3. Component shown by the sub-code	AV-32

DTC No.	Detection Item	Trouble Area	See page
01-DB	Mode Status Error	1. Power source circuit of the component shown by the sub-code 2. AVC-LAN circuit between the radio receiver and the component shown by the sub-code 3. Component shown by the sub-code	AV-32
01-DC	Transmission Error	If the same sub-code is recorded in other components, check harness for power supply and communication system of all components shown by code	AV-39
01-DD	Master Reset	1. Radio receiver power source circuit 2. AVC-LAN circuit between the radio receiver and the component which has stored this code 3. Radio receiver 4. Component which has stored this code	AV-42
01-DE	Slave Reset	1. Power source circuit of the component shown by the sub-code 2. AVC-LAN circuit between the radio receiver and the component shown by the sub-code 3. Component shown by the sub-code	AV-32
01-DF	Master Error	1. Radio receiver power source circuit 2. AVC-LAN circuit between the radio receiver and the component which has stored this code 3. Radio receiver 4. Component which has stored this code	AV-47
01-E0	Registration Complete Indication Error	-	AV-52
01-E1	Voice Processing Device ON Error	1. Radio receiver power source circuit 2. AVC-LAN circuit between the radio receiver and the component which has stored this code 3. Radio receiver 4. Component which has stored this code	AV-42
01-E2	ON / OFF Indication Parameter Error	Radio receiver	AV-53
01-E3	Registration Demand Transmission	-	AV-52
01-E4	Multiple Frame Incomplete	-	AV-52

DVD PLAYER:

DTC No.	Detection Item	Trouble Area	See page
44-10	DVD Player Mechanical Error	Television display assembly	AV-54
44-11	DVD Insertion and Eject Error	Television display assembly	AV-54
44-12	DVD Reading Abnormal	Television display assembly	AV-54
44-41	Wrong Disc	1. DVD 2. Television display assembly	AV-55
44-42	Disc cannot be Read	1. DVD 2. Television display assembly	AV-55

DTC No.	Detection Item	Trouble Area	See page
44-43	DVD-ROM Abnormal	1. DVD 2. Television display assembly	AV-57
44-44	DVD Error	Television display assembly	AV-58
44-45	Eject Error	Television display assembly	AV-59
44-47	High Temperature	Television display assembly	AV-62
44-48	Excess Current	Television display assembly	AV-58
44-50	Tray Insertion / Ejection Error	Television display assembly	AV-58
44-51	Elevator Error	Television display assembly	AV-59
44-78	DSP Error	-	AV-63

CD PLAYER

DTC No.	Detection Item	Trouble Area	See page
62-10	CD Player Mechanical Error	Radio receiver	AV-65
62-11	CD Insertion and Eject Error	Radio receiver	AV-65
62-12	CD Reading Abnormal	Radio receiver	AV-65
62-41	Wrong Disc	1. CD 2. Radio receiver	AV-66
62-42	Disc cannot be Read	1. CD 2. Radio receiver	AV-66
62-43	CD-ROM Abnormal	1. CD 2. Radio receiver	AV-68
62-44	CD Abnormal	Radio receiver	AV-70
62-45	Eject Error	Radio receiver	AV-71
62-46	Scratched / Reversed Disc	1. CD 2. Radio receiver	AV-72
62-47	High Temperature	Radio receiver	AV-74
62-48	Excess Current	Radio receiver	AV-70
62-50	Tray Insertion / Ejection Error	Radio receiver	AV-70
62-51	Elevator Error	Radio receiver	AV-71
62-52	Clamp Error	Radio receiver	AV-71
62-78	DSP Error	-	AV-75

IN-DASH CD CHANGER

DTC No.	Detection Item	Trouble Area	See page
63-10	CD Changer Mechanical Error	Radio receiver	AV-65
63-11	CD Insertion and Eject Error	Radio receiver	AV-65
63-12	CD Reading Abnormal	Radio receiver	AV-65
63-41	Wrong Disc	1. CD 2. Radio receiver	AV-66
63-42	Disc cannot be Read	1. CD 2. Radio receiver	AV-66
63-43	CD-ROM Abnormal	1. CD 2. Radio receiver	AV-68
63-44	CD Abnormal	Radio receiver	AV-70
63-45	Eject Error	Radio receiver	AV-71
63-46	Scratched / Reversed Disc	1. CD 2. Radio receiver	AV-72
63-47	High Temperature	Radio receiver	AV-74
63-48	Excess Current	Radio receiver	AV-70
63-50	Tray Insertion / Ejection Error	Radio receiver	AV-70
63-51	Elevator Error	Radio receiver	AV-71
63-52	Clamp Error	Radio receiver	AV-71
63-78	DSP Error	-	AV-75

DTC No.	Detection Item	Trouble Area	See page
44-46	Scratched / Reversed Disc		AV-60
44-7D	Disc cannot be Played		AV-64
44-7F	Copyright Protection Error		AV-64
62-7D	Disc cannot be Played		AV-76
62-7E	No Playable Files		AV-76
62-7F	Copyright Protection Error		AV-76
63-7D	Disc cannot be Played		AV-76
63-7E	No Playable Files		AV-76
63-7F	Copyright Protection Error		AV-76
44-52	Clamp Error		AV-59
44-7E	No Playable Files		AV-64