Pressing Power Switch does not Turn on System

INSPECTION PROCEDURE

1	CHECK CABIN

(a) Check that conditions in the cabin are not likely to cause condensation.
HINT:
This problem occurs when the cabin is humid and the temperature rapidly changes. This condition may produce condensation, resulting in a short circuit.
OK:
Condensation is not likely to occur.

NG → **DRY CABIN AND RECHECK CONDITIONS**

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

No Sound can be Heard from Speakers

INSPECTION PROCEDURE

1	CHECK AUDIO SETTINGS



(a) Enter the sound adjustment screen by pressing the "SOUND" switch on the AUDIO display.
(b) Set volume, fader, and balance to the initial values and check that sound is normal.
OK:
Audio system returns to normal.
HINT:
Sound quality adjustment items vary depending on the type of the amplifier.

OK → **END**

NG

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE