

INSTALLATION

1. **INSTALL NAVIGATION ANTENNA ASSEMBLY**
2. **INSTALL INSTRUMENT PANEL SAFETY PAD SUB-ASSEMBLY**
   (a) Using a torque wrench, install the bolt <B>.



Torque: 20 N*m (204 kgf*cm, 14 ft.*lbf)



3. **INSTALL SHIFT LEVER ASSEMBLY**
   (a) Using a torque wrench, install the 4 bolts.
   Torque: 21 N*m (214 kgf*cm, 12.6 ft.*lbf)
4. **INSTALL DEFROSTER NOZZLE OPENING PLATE NO.1**
5. **INSTALL FRONT NO.2 SPEAKER ASSEMBLY**
6. **INSTALL FRONT NO.1 SPEAKER ASSEMBLY**
7. **INSTALL INSTRUMENT PANEL SPEAKER PANEL SUB-ASSEMBLY NO.2**
8. **INSTALL INSTRUMENT PANEL SPEAKER PANEL SUB-ASSEMBLY**
9. **INSTALL FRONT PILLAR GARNISH RH**
10. **INSTALL FRONT PILLAR GARNISH LH**
11. **INSTALL INTEGRATION CONTROL & PANEL ASSEMBLY**

NS

12. **INSTALL NAVIGATION RECEIVER ASSEMBLY**
13. **INSTALL STEREO COMPONENT SPEAKER ASSEMBLY**
14. **INSTALL INSTRUMENT CLUSTER FINISH PANEL GARNISH**
15. **INSTALL INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY LOWER CENTER**
16. **INSTALL INSTRUMENT CLUSTER FINISH PANEL ASSEMBLY CENTER**
17. **INSTALL FLOOR SHIFT POSITION INDICATOR HOUSING ASSEMBLY**
18. **INSTALL SHIFT LEVER KNOB SUB-ASSEMBLY**
19. **INSTALL INSTRUMENT CLUSTER FINISH PANEL CENTER NO.2**
20. **INSTALL INSTRUMENT CLUSTER FINISH PANEL CENTER NO.1**
21. **INSTALL FLOOR CARPET COVER CENTER RH**
22. **INSTALL FLOOR CARPET COVER CENTER LH**
23. **INSTALL INSTRUMENT PANEL REGISTER ASSEMBLY NO.3**
24. **INSTALL INSTRUMENT PANEL REGISTER ASSEMBLY NO.1**
25. **INSTALL INSTRUMENT SIDE PANEL RH**
26. **INSTALL INSTRUMENT SIDE PANEL LH**
27. **INSTALL INSTRUMENT PANEL BOX NO.2**
28. **INSTALL GLOVE COMPARTMENT DOOR ASSEMBLY**
29. **INSTALL GLOVE COMPARTMENT DOOR STOPPER SUB-ASSEMBLY**
30. **INSTALL INSTRUMENT PANEL SAFETY PAD INSERT SUB-ASSEMBLY NO.1**
31. **INSTALL INSTRUMENT PANEL FINISH PANEL SUB-ASSEMBLY LOWER LH**
32. **INSTALL COWL SIDE TRIM BOARD RH**
33. **INSTALL COWL SIDE TRIM BOARD LH**
34. **INSTALL FRONT DOOR SCUFF PLATE RH**
35. **INSTALL FRONT DOOR SCUFF PLATE LH**
36. **INSTALL COMBINATION METER ASSEMBLY**
37. **INSTALL INSTRUMENT CLUSTER FINISH PANEL SUB-ASSEMBLY**
38. **INSTALL WINDSHIELD WIPER SWITCH ASSEMBLY**
39. **INSTALL HEADLIGHT DIMMER SWITCH ASSEMBLY**
40. **INSTALL SPIRAL CABLE SUB-ASSEMBLY**

41. INSTALL STEERING COLUMN COVER
42. ADJUST SPIRAL CABLE SUB-ASSEMBLY (See page RS-435)
43. INSTALL STEERING WHEEL ASSEMBLY (See page SR-11)
44. INSTALL HORN BUTTON ASSEMBLY (See page RS-424)
45. INSTALL STEERING WHEEL COVER LOWER NO.2
46. INSTALL STEERING WHEEL COVER LOWER NO.3
47. CONNECT BATTERY NEGATIVE TERMINAL
48. INSPECT HORN BUTTON ASSEMBLY (See page RS-425)
49. INSPECT SRS WARNING LIGHT (See page RS-436)