

REMOVAL

1. **REMOVE INSTRUMENT CLUSTER CENTER NO. 1 FINISH PANEL (See page IP-8)**
2. **REMOVE INSTRUMENT CLUSTER CENTER NO. 2 FINISH PANEL**
3. **REMOVE SHIFT LEVER KNOB SUB-ASSEMBLY (See page IP-8)**
4. **REMOVE POSITION INDICATOR HOUSING ASSEMBLY (See page IP-9)**
5. **REMOVE INSTRUMENT CLUSTER CENTER LOWER FINISH PANEL SUB-ASSEMBLY (See page IP-9)**
6. **REMOVE CIGARETTE LIGHTER COVER**
   (a) Release the 2 claw fittings and remove the cigarette lighter cover.
7. **REMOVE CIGARETTE LIGHTER ASSEMBLY**
   (a) Remove the cigarette lighter knob.







   (b) Release the 2 claw fittings and remove the cigarette lighter assembly.

INSTALLATION

1. **INSTALL CIGARETTE LIGHTER ASSEMBLY**
   (a) Engage the 2 claws to install the cigarette lighter assembly.
   (b) Install the cigarette lighter knob.



OT



2. INSTALL CIGARETTE LIGHTER COVER

(a) Engage the 2 claws to install the cigarette lighter cover.

3. INSTALL INSTRUMENT CLUSTER CENTER LOWER FINISH PANEL SUB-ASSEMBLY

4. INSTALL POSITION INDICATOR HOUSING ASSEMBLY

5. INSTALL SHIFT LEVER KNOB SUB-ASSEMBLY

6. INSTALL INSTRUMENT CLUSTER CENTER NO. 2 FINISH PANEL

7. INSTALL INSTRUMENT CLUSTER CENTER NO. 1 FINISH PANEL