INSTALLATION

1. **INSTALL SIDE REAR WINDOW WEATHERSTRIP LH**
2. **INSTALL QUARTER WINDOW LOCK ASSEMBLY LH**
3. **INSTALL POWER VENT WINDOW MOTOR ASSEMBLY LH**
4. **INSTALL SIDE WINDOW ASSEMBLY REAR LH**
5. **INSTALL RR WINDOW SIDE GARNISH ASSEMBLY LH**
6. **INSTALL RR WINDOW SIDE GARNISH ASSEMBLY NO.2 LH**
7. **REMOVE QUARTER TRIM PANEL ASSEMBLY LH**
8. **INSTALL REAR DOOR SCUFF PLATE LH**
9. **INSTALL ROOF HEADLINING GARNISH REAR**
10. **INSTALL BACK DOOR SCUFF PLATE**
11. **INSTALL ROPE HOOK ASSEMBLY**
12. **INSTALL REAR DOOR WEATHERSTRIP LH**
13. **INSTALL REAR NO. 1 SEAT ASSEMBLY LH**
    HINT:
    - Captain seat type: See page SE-75
    - Center seat type: See page SE-82