DISASSEMBLY


1. **REMOVE SIDE DEFROSTER NOZZLE DUCT NO.1**
   (a) Remove the 2 screws <C> and defroster nozzle duct No. 1.
2. **REMOVE SIDE DEFROSTER NOZZLE DUCT NO.2**
   (a) Remove the 2 screws <C> and defroster nozzle duct No. 2.
3. **REMOVE DEFROSTER NOZZLE ASSEMBLY**
   (a) Remove the 4 screws <C> and defroster nozzle assembly.
4. **REMOVE HEATER TO REGISTER DUCT NO.1**
   (a) Remove the 3 screws <C> and heater to register duct No. 1.
5. **REMOVE HEATER TO REGISTER DUCT NO.2**
   (a) Remove the 3 screws <C> and heater to register duct No. 2.
6. **REMOVE HEATER TO REGISTER DUCT NO.3**
   (a) Remove the 2 screws <C> and heater to register duct No. 3.
7. **REMOVE SIDE DEFROSTER NOZZLE LH**
8. **REMOVE SIDE DEFROSTER NOZZLE RH**
9. **REMOVE INSTRUMENT PANEL FINISH PANEL RETAINER LOWER NO.3**
   (a) Remove the 2 screws <C> and instrument panel finish panel retainer lower No. 3.
10. **REMOVE INSTRUMENT CLUSTER FINISH PANEL REINFORCEMENT**
    (a) Remove the screw <C> and instrument cluster finish panel reinforcement.
11. **REMOVE DEFROSTER DUCT BRACKET NO.1**
    (a) Remove the screw <C> and defroster duct bracket No. 1.
12. **REMOVE INSTRUMENT FINISH PANEL RETAINER LOWER**
    (a) Remove the screw <C> and instrument finish panel retainer lower.
13. **REMOVE INSTRUMENT FINISH PANEL RETAINER LOWER NO.2**
    (a) Remove the screw <C> and instrument finish panel retainer lower No. 2.
14. **REMOVE INSTRUMENT PANEL FINISH PANEL RETAINER NO.1**
    (a) Remove the 2 screws <C> and instrument panel finish panel retainer No. 1.
15. **REMOVE INSTRUMENT PANEL BOX DOOR SUB-ASSEMBLY NO.2**
16. **REMOVE ANTENNA CORD SUB-ASSEMBLY**

17. REMOVE NAVIGATION ANTENNA ASSEMBLY (w/ Navigation System)

18. REMOVE INSTRUMENT PANEL WIRE NO.2

(a) Remove the 2 screws <C>.

(b) Disengage the 7 clamps and remove the instrument panel wire No. 2.



19. REMOVE INSTR PNL PASS L/DOOR AIR BAG ASSEMBLY (See page RS-439)