

REAR NO. 2 SEAT ASSEMBLY (for Power Seat Type LH Side)


COMPONENTS



SE


REAR NO. 2 SEAT HEADREST SUPPORT ASSEMBLY RH
REAR SEAT HEADREST ASSEMBLY
REAR NO. 2 SEAT HEADREST SUPPORT ASSEMBLY LH
NO. 2 SEATBACK PAD
CLIP
CLIP
HOG RING
NO. 2 SEATBACK COVER SUB-ASSEMBLY
NO. 2 SEATBACK FRAME SUB-ASSEMBLY
44 (449, 33)
FOLD SEAT CONTROL ECU
REAR NO. 2 SEAT COVER BEZEL
REAR SEAT RECLINING COVER RH
44 (449, 33)
REAR SEAT RECLINING COVER LH
N*m (kgf*cm, ft.*lbf): Specified torque
Non-reusable part
P
B126831E01

SE



N*m (kgf*cm, ft.*lbf): Specified torque

● Non-reusable part

P

B126830E01

SE