

# SYSTEM DIAGRAM




SE


Power Rear No. 2
Seat Switch
RCLF
RCLR
Lock Switches
1
2
3
4
LCKF
LCKR
Fold Lock Switch
Fold Seat
Control ECU
RACT
IND2
M
Release
Actuator
IG
3rd SEAT Indicator
H
B129674E01

SE