HOW TO PROCEED WITH TROUBLESHOOTING

HINT:

- Use these procedures to troubleshoot the power folding seat system.
- *: Use the intelligent tester.

1 **VEHICLE BROUGHT TO WORKSHOP**

NEXT

2 **INSPECT BATTERY VOLTAGE**

Standard voltage:
10 to 14 V

If the voltage is below 11 V, recharge or replace the battery before proceeding.

NEXT

3 **PROBLEM SYMPTOMS TABLE**

Result

Result	Proceed to
Fault is not listed in problem symptoms table	A
Fault is listed in problem symptoms table	B

B → **Go to step 5**

A

4 **OVERALL ANALYSIS AND TROUBLESHOOTING***

(a) Terminals of ECU
(b) On-vehicle Inspection

NEXT

5 **REPAIR OR REPLACE**

NEXT

SE

6	**CONFIRMATION TEST**

NEXT

END