
ON-VEHICLE INSPECTION

1. CHECK POWER REAR NO. 2 SEAT with STOWING FUNCTION


(a) Check the basic functions.

(1) Operate the fold seat switch and power rear No.2 seat switch and check to make sure each seat function works:


Reclining:



Folding, Return, Stowing:



Fold Seat Switch



H

B129719E01

- Folding-down operation
- Stowing operation
- Return operation
- Reclining operation

SE