

REAR BUMPER

COMPONENTS



ET



REMOVAL

1. REMOVE REAR BUMPER COVER

(a) Put protective tape under the quarter panel.

(b) Partially the fender liner.
HINT:
Do not remove the fender liner completely but partially so that the bumper cover can be removed.

(c) Remove the 2 screws and 8 clips.

(d) Using a screwdriver, disengage the claws and remove the cover.
HINT:
Tape the screwdriver tip before use.