INSTALLATION

1. INSTALL ROOF DRIP SIDE FINISH MOULDING

(a) When exchanging the clips

(1) Remove the tape that remains on the mounting surface of the vehicle body and then clean the surface with white gasoline.

(2) Using a heat light, heat up the clip installation surfaces of the vehicle body and moulding.

Heating temperature:

Body	40 to 60 °C (104 to 140 °F)
Moulding	20 to 30 °C (68 to 86 °F)

NOTICE:
Do not heat the body and moulding excessively.

(3) Set the supply clips in the positions as shown in the illustration and press-fit the clips by hand to install them.

NOTICE:
Install the moulding when 30 minutes or more have passed after press-fitting the clips.

HINT:

- Install hardening time: 30 minutes
- Perfect hardening time: 24 hours

(b) Install the roof drip side finish moulding.

