

REAR DOOR GLASS WEATHERSTRIP

COMPONENTS



REMOVAL

1. **REMOVE REAR WINDOW SIDE GARNISH ASSEMBLY**
2. **REMOVE REAR DOOR WINDOW FRAME SUB-ASSEMBLY**
3. **REMOVE SIDE TRIM BOARD COVER REAR (See page ED-190)**
4. **REMOVE REAR DOOR TRIM BOARD SUB-ASSEMBLY (See page ED-190)**
5. **REMOVE REAR DOOR GLASS RUN**
6. **REMOVE SLIDE DOOR WINDOW ASSEMBLY (See page ED-191)**
7. **REMOVE REAR DOOR GLASS WEATHERSTRIP**
   (a) Put protective tape under the rear door glass weatherstrip.
   (b) Using a screwdriver or moulding remover, remove the rear door glass weatherstrip.
   HINT:
   Tape the screwdriver tip before use.



ET