

* 1:2WD
* 2:4WD
* 5:Before Aug. 2011 Production
* 6:From Aug. 2011 Production

L	1	Front Door Courtesy Light Switch Assembly RH
L	2	Rear Door Courtesy Light Switch Assembly RH
L	3	Rear Door Courtesy Light Switch Assembly LH
L	4	Front Door Courtesy Light Switch Assembly LH
L	5	Rear Combination Light Assembly RH
L	6	Rear Combination Light Assembly LH
L	7	Fuel Sender Gauge Assembly
L	14	No. 2 Room Light Assembly
L	15	Door Control Receiver
L	17	Rear Side Airbag Sensor Assembly RH
L	18	Rear Side Airbag Sensor Assembly LH
L	19	Front Side Airbag Sensor Assembly RH
L	20	Front Side Airbag Sensor Assembly LH
L	23	Front Pretensioner RH
L	24	Front Pretensioner LH
L	25	Curtain Shield Airbag Assembly RH
L	26	Curtain Shield Airbag Assembly LH
L	30	Junction Connector
L	31	Junction Connector
L	32	Diode (Rear Room Light)
L	33	Noise Filter (Rear Window Defogger)
L	36	Rear Indoor Electrical Key Oscillator
L	37	Outside Luggage Electrical Key Antenna
L	38	Rear Seat Inner Belt Assembly RH
L	39	Rear Seat Inner Belt Assembly LH
L	40	Fuel Sender Gauge Assembly
L	41	Rear Seat Inner Belt Assembly LH
L	42	Rear Seat Inner Belt Assembly RH
L	43	Rear Speed Sensor LH
L	44	Rear Speed Sensor RH
L	45	Rear Side Airbag Sensor Assembly RH
L	46	Rear Side Airbag Sensor Assembly LH
L	47	Front Side Airbag Sensor Assembly RH
L	48	Front Side Airbag Sensor Assembly LH

L 1
White

L 2
White

L 3
White

L 4
White

L 5
White

L 6
White

L 7
White

L 14
White

L 15
White



L 17
Yellow



L 18
Yellow



L 19
Yellow



L 20
Yellow



L 23
Yellow



L 24
Yellow



L 25
Black



L 26
Black



L 30
White



L 31
White



L 32
Black

L 33
White



L 36
White



L 37
White



L 38
Black



L 39
Black



L 40
White

L 41
Gray



L 42
Black



L 43
White



L 44
White

L 45
Yellow



L 46
Yellow



L 47
Yellow



L 48
Yellow