(Cont. next page)




Air Conditioner
5
6
7
8
* 5 : w/ PTC Heater
* 6 : 1NR–FE
* 8 : 1KR–FE
(IG)
7. 5A
A/C
(BAT)
80A
PTC
H–LP/US–DRL Relay
<2–14>
Multiplex Communication
System (CAN)<2–3>
F41
A/C Amplifier Assembly
HLS
TX+
TX–
PTC3
PTC2
PTCB
PTCC
IG1
ALT
Integration Relay
PTCA
PTC3
PTC1
PTC2
GND1
GND2
SG–2
S5–3
PRE
SOL+
PTC1
A23
A/C Pressure Sensor
(Liquid Tube Sub-Assembly)
B77
With Pulley Compressor Assembly
A44
Quick Heater Assembly
A2
A5
BR
(*6)
W–B
(*8)