Position of Parts in Instrument Panel <RHD>



F 1 Combination Meter Assembly
F 2 Combination Meter Assembly
F 3 DLC3
F 4 Spiral Cable Sub-Assembly
F 5 Power Steering ECU Assembly
F 6 Outer Mirror Switch Assembly
F 7 Headlight Leveling Switch
F 8 Headlight Dimmer Switch Assembly
F 9 Windshield Wiper Switch Assembly
F 10 Windshield Wiper Switch Assembly
F 11 Ignition or Starter Switch Assembly
F 12 Key Inter Lock Solenoid
F 13 Un-Lock Warning Switch Assembly
F 14 Airbag Sensor Assembly
F 15 Spiral Cable Sub-Assembly
F 16 Lower No. 1 Instrument Panel Airbag Assembly
F 17 Airbag Cut Off Switch Cylinder Sub-Assembly
F 18 Telltale Light Assembly
F 19 Parking Brake Switch Assembly
F 20 Shift Lock Control Unit Assembly
F 21 Shift Position Indicator (Indicator Light Wire Sub-Assembly)

F 1
Black



F 2
White



F 3
White



F 4
Black



F 5
Black



F 6
White



F 7
Black



F 8
Black



F 9
White



F 10
White



F 11
White



F 12
Black



F 13
White



F 14
Yellow



F 15
Yellow



F 16
Black



F 17
White



F 18
Black



F 19
White

F 20
White



F 21

White