

* 3:From Aug. 2008 Production
until Aug. 2010 Production A/T w/o ABS,
From Aug. 2010 Production
* 4:Except *3

C 1 Starter
C 2 Crankshaft Position Sensor
C 3 VSV (Purge)
C 4 Fuel Injector (No.1)
C 5 Fuel Injector (No.2)
C 6 Fuel Injector (No.3)
C 7 Fuel Injector (No.4)
C 8 A/C Compressor
C 9 Alternator
C 10 Alternator
C 11 Ignition Coil (No.1)
C 12 Ignition Coil (No.2)
C 13 Ignition Coil (No.3)
C 14 Ignition Coil (No.4)
C 15 Starter
C 16 Engine Oil Pressure SW
C 17 Throttle Body Assembly
C 18 Camshaft Position Sensor
C 19 Water Temp. Sensor
C 20 Engine ECU
C 22 Back-Up Lamp SW
C 23 Speed Sensor
C 24 Camshaft Timing Oil Control Valve
C 25 Noise Filter (Ignition)
C 26 Air Flow Meter
C 27 Park/Neutral Position SW
C 28 ECT Solenoid
C 29 Speed Sensor (Turbine)
C 30 Fusible Link Block
C 36 Oxygen Sensor (Bank 1 Sensor 1)
C 37 Variable Resistor
C 74 Noise Filter (Ignition)

P 1 Knock Control Sensor (Bank 1)

C 1



C 2
Black



C 3
Blue



C 4
Black



C 5
Gray



C 6
Black



C 7
Gray



C 8
Gray



C 9
Black

C 10



(Except 2SZ-FE)

C 11
Black



C 12
Gray

C 13
Black



C 14
Gray

C 15
Black

C 16
Gray

C 17
Black



C 18
Black

C 19
Black

C 20
Black



C 22
Gray



C 23
Black

C 24
Black

C 25
Gray

(Except 2ZR-FE From Aug. 2008 Production)

C 26
Black



C 27
Gray



C 28
Gray



C 29
Black



C 30



C 36
Dark Gray

C 37
Black

C 74
Gray



P 1
Black