




## Spark Plug Inspection

1. Inspect the electrodes and ceramic insulator for:



**Burned or worn electrodes may be caused by:**

- Lean fuel mixture
- Advanced ignition timing
- Loose spark plug
- Plug heat range too high
- Insufficient cooling

**Fouled plug may be caused by:**

- Rich fuel mixture
- Retarded ignition timing
- Oil in combustion chamber
- Incorrect spark plug gap
- Plug heat range too low
- Excessive idling/low speed running
- Clogged air cleaner element
- Deteriorated ignition coil or ignition wires


2. Replace the plug if the center electrode is rounded as shown below:

**Spark Plug:**

BCPR6E-11 (NGK), Q20PR-U11 (ND)  
 BCPR6EY-N11 (NGK)\*2  
 BCPR7E-11 (NGK), Q22PR-U11 (ND)  
 BCPR7EY-N11 (NGK)\*2  
 BCPR5E-11 (NGK)\*1, Q16PR-U11 (ND)\*1  
 BCPR5EY-N11 (NGK)\*1  
 (or equivalent)

\*1: KQ only

\*2: With catalytic converter



3. Adjust the gap with a suitable gapping tool.

**Electrode Gap: 1.0–1.1 mm (0.039–0.043 in)**

4. Screw the plugs into the cylinder head finger tight, then torque them to 22 N·m (2.2 kg·m, 16 lb·ft).

**NOTE:** Apply a small quantity of anti-seize compound to the plug threads before installing.