## TROUBLESHOOTING

CL07J-01

## PROBLEM SYMPTOMS TABLE

Use the table below to help you find the cause of the problem. The numbers indicate the priority of the likely cause of the problem. Check each part in order. If necessary, replace these parts.

Symptom	Suspect Area	See page
Clutch grabs/chatters	Engine mounting (Loosen)	-
	2. Clutch disc (Runout is excessive)	CL-14
	3. Clutch disc (Oily)	CL-14
	4. Clutch disc (Worn out)	CL-14
	5. Clutch disc (Damaged torsion rubber)	CL-14
	6. Clutch disc (Glazed)	CL-14
	7. Diaphragm spring (Out of tip alignment)	CL-17
Clutch pedal spongy	1. Clutch line (Air in line)	-
	2. Master cylinder cup (Damaged)	CL-4
	3. Release cylinder cup (Damaged)	CL-9
Clutch noisy	1. Release bearing (Worn, dirty or damaged)	CL-14
	2. Pilot bearing (Worn or damaged)	CL-14
	3. Input shaft bearing (Worn, dirty or damaged)	_
	4. Clutch disc torsion rubber (Damaged)	CL-14
Clutch slips	Clutch pedal (Freeplay out of adjustment)	CL-2
	2. Clutch disc (Oily)	CL-14
	3. Clutch disc (Worn out)	CL-14
	4. Diaphragm spring (Damaged)	CL-14
	5. Pressure plate (Distortion)	CL-14
	6. Flywheel (Distortion)	-
Clutch does not disengage	Clutch pedal (Freeplay out of adjustment)	CL-2
	2. Clutch line (Air in line)	_
	3. Master cylinder cup (Damaged)	CL-4
	4. Release cylinder cup (Damaged)	CL-9
	5. Input shaft bearing (Worn, dirty or damaged)	-
	6. Pilot bearing (Worn or damaged)	CL-14
	7. Clutch disc (Out of true)	CL-14
	8. Clutch disc (Runout is excessive)	CL-14
	9. Clutch disc (Lining broken)	CL-14
	10. Clutch disc (Dirty or burred)	CL-14
	11. Clutch disc (Oily)	CL-14
	12. Clutch disc (Lack of spline grease)	CL-17
	13. Diaphragm spring (Damaged)	CL-14
	14. Diaphragm spring (Out of tip alignment)	CL-17
	15. Pressure plate (Distortion)	CL-14