

BODY

GENERAL MAINTENANCE

1. TIGHTEN BOLTS AND NUTS ON CHASSIS AND BODY

- (a) Where necessary, tighten all the parts of the chassis.
 - Front axle and suspension
 - Drive train
 - Rear axle and suspension
 - Brake system
 - Engine mounting, etc.
- (b) Where necessary, tighten all the parts of the body.
 - Seat belt system
 - Seat
 - Doors and hood
 - Body mountings
 - Fuel tank
 - Exhaust pipe system, etc.

2. REPLACE AIR CONDITIONING FILTER

- (a) Remove the glove compartment assembly.
- (b) Remove the filter case from the filter outlet.
- (c) Remove the filter from the filter case.
- (d) Replace the filter with a new one.
- (e) Installation is in the reverse order.

3. ROAD TEST

- (a) Check the engine and chassis for abnormal noises.
- (b) Check that the vehicle does not wander or pull to one side.
- (c) Check that the brakes work properly and do not drag.
- (d) Do setting of the parking brake shoes.

4. BODY INSPECTION

- (a) Check the body exterior for dents, scratches and rust.
- (b) Check the underbody for rust and damage. If necessary, replace or repair.

5. FINAL INSPECTION

- (a) Check the operation of the body parts.
 - (1) Hood
 - Auxiliary catch operates properly.
 - Hood locks securely when closed.
 - (2) Front and rear doors
 - Door locks operate properly.
 - Doors close properly.
 - (3) Back door
 - Door lock operates properly.
 - (4) Seats
 - Seat adjusts easily and locks securely in any position.
 - Front seatback locks securely in any position.

- Folding-down rear seatbacks lock securely.
- (5) Be sure to deliver a clean car. Especially check.
- Steering wheel
 - Shift lever knob
 - All switch knobs
 - Door handles
 - Seats