


## 7. Rear Disc Brake Assembly

### A: REMOVAL


#### CAUTION:

Do not allow brake fluid to come in contact with the painted surface of the vehicle body. If it does, wash off with water and wipe away completely.

- 1) Lift up the vehicle, and then remove the rear wheels.
- 2) Remove the caliper body from support.
  - (1) Remove the brake hose bracket and union bolt.



- (2) Remove the caliper bolt, and remove the caliper body.



- 3) Remove the support.

#### NOTE:

Remove the support only when replacing the disc rotor or support. It is not necessary to remove it when servicing the caliper body.


- (1) Remove the brake pad from support.
- (2) Remove the mounting bolts, and then remove the support from the rear axle housing.

## B: INSTALLATION

### NOTE:

Before installation, remove mud and foreign matter from the caliper body and support.

- 1) Before installation, check each part. <Ref. to BR-38, INSPECTION, Rear Disc Brake Assembly.>
- 2) Apply a thin coat of grease contained in the pad kit to the support.




- 3) Install the support to the rear axle housing.

### **Tightening torque:**

**Mounting bolt: 66 N·m (6.73 kgf-m, 48.7 ft-lb)**

- 4) Apply a thin coat of Molykote M7439 (Part No. 003602001) or grease contained in the pad kit to the pad clip.




# Rear Disc Brake Assembly

## BRAKE

5) Apply a thin coat of grease to the inner shim (a) and the outer shim (b).

### Grease:

**Grease contained in the pad kit or WAKO grease V160**



(A) Outer pad

(B) Inner pad

6) Install the brake pad to the support.

7) Install the caliper body to the support.

### Tightening torque:

**Caliper bolt: 27 N·m (2.75 kgf-m, 19.9 ft-lb)**

8) Install the brake hose bracket.

### Tightening torque:

**Brake hose bracket: 33 N·m (3.4 kgf-m, 14.3 ft-lb)**

9) Connect the brake hose using a new brake hose gasket.

### Tightening torque:

**Union bolt: 18 N·m (1.84 kgf-m, 13.3 ft-lb)**

10) Bleed air from the brake system. <Ref. to BR-52, BRAKE LINE, PROCEDURE, Air Bleeding.>

11) Install the rear wheels.


## C: DISASSEMBLY

### CAUTION:

**Be careful not to allow foreign matter to enter the brake hose connector.**

1) Remove mud and foreign matter from the caliper body.

2) Remove the piston boot from caliper body cylinder.




BR-00041

3) Remove the piston.

(1) Place a wooden block in the caliper body as shown in the figure to prevent the piston from jumping out and being damaged.

(2) Using an air gun, gradually apply compressed air via the brake hose installation hole to push the piston out.




(1) Place a wooden block of 30 mm (1.18 in) width.


4) Remove the piston seal from caliper body cylinder.

**CAUTION:**

**Do not damage the cylinder and piston seal groove.**



5) Remove the guide pin, lock pin, bushing pin, and pin boot from the support.



(a) Guide pin (black)  
(b) Lock pin (silver)

(c) Bushing

(d) Pin boot

# Rear Disc Brake Assembly

## BRAKE


### D: ASSEMBLY

- 1) Before installation, check each part. <Ref. to BR-38, INSPECTION, Rear Disc Brake Assembly.>
- 2) Clean the inside of the caliper body cylinder using brake fluid.
- 3) Apply a coat of brake fluid to piston seal and install the piston seal to the caliper body cylinder groove.
- 4) Apply a coat of brake fluid to the inner surface of caliper body cylinder and the entire outer surface of the piston.
- 5) Apply grease contained in the piston seal kit to the piston boot, and install it to the groove at the end of the cylinder.
- 6) Insert the piston into caliper body cylinder.

#### CAUTION:

**Do not force the piston into caliper body cylinder.**

- 7) Position the piston boot in the grooves on caliper body cylinder and piston.




- (1) Piston
- (2) Piston boot
- (3) Caliper body
- (4) Piston seal

- 8) Apply grease contained in the piston seal kit to the lock pin, guide pin outer surface, support cylinder inner surface, and pin boot grooves.
- 9) Install the pin boot to the lock pin and guide pin, and insert it into the support cylinder.

#### CAUTION:

**Insert the lock pin and guide pin into specified position, and make sure that they slide and seat properly.**



- (1) Pin boot
- (2) Lock pin or guide pin
- (3) Grease applied area

### E: INSPECTION

- 1) Check the caliper body cylinder and piston for uneven wear, damage or rust.
- 2) Check the rubber parts for damage or deterioration.
- 3) If faulty is found in the inspection, replace the relevant part.