

General Diagnostic Table

DRIVE SHAFT SYSTEM

9. General Diagnostic Table

A: INSPECTION

NOTE:

Vibration while cruising may be caused by an unbalanced tire, improper tire inflation pressure, improper wheel alignment, etc.

| Symptoms | Possible cause | Corrective action |
|--|--|--|
| Noise or vibration from propeller shaft | <ul style="list-style-type: none"> • Center bearing • Runout of propeller shaft • Loose or gap at connections | Inspect the propeller shaft. <Ref. to DS-12, INSPECTION, Propeller Shaft.> |
| Abnormal wheel vibration | Wheel is out of balance. | Check the wheel balance. <Ref. to WT-5, WHEEL BALANCING, INSPECTION, Tire and Wheel.> |
| | Front wheel alignment | Check the front wheel alignment. <Ref. to FS-9, INSPECTION, Wheel Alignment.> |
| | Rear wheel alignment | Check the rear wheel alignment. <Ref. to RS-9, INSPECTION, Wheel Alignment.> |
| | Front strut | Check the front strut. <Ref. to FS-45, INSPECTION, Front Strut.> |
| | Rear shock absorber | Check the rear shock absorber. <Ref. to RS-21, INSPECTION, Rear Shock Absorber.> |
| | Front drive shaft | Check the front drive shaft. <Ref. to DS-56, INSPECTION, Front Drive Shaft.> |
| | Rear drive shaft | Check the rear drive shaft. <Ref. to DS-65, INSPECTION, Rear Drive Shaft.> |
| | Front hub unit bearing | Check the front hub unit bearing. <Ref. to DS-29, INSPECTION, Front Hub Unit Bearing.> |
| | Rear hub unit bearing | Check the rear hub unit bearing. <Ref. to DS-47, INSPECTION, Rear Hub Unit Bearing.> |
| Noise from the underbody | Wheel is out of balance. | Check the wheel balance. <Ref. to WT-5, WHEEL BALANCING, INSPECTION, Tire and Wheel.> |
| | Front wheel alignment | Check the front wheel alignment. <Ref. to FS-9, INSPECTION, Wheel Alignment.> |
| | Rear wheel alignment | Check the rear wheel alignment. <Ref. to RS-9, INSPECTION, Wheel Alignment.> |
| | Front strut | Check the front strut. <Ref. to FS-45, INSPECTION, Front Strut.> |
| | Rear shock absorber | Check the rear shock absorber. <Ref. to RS-21, INSPECTION, Rear Shock Absorber.> |

VEHICLE DYNAMICS CONTROL (VDC)

VDC

| | Page |
|--|-------------|
| 1. General Description | 2 |
| 2. Relay and Fuse | 8 |
| 3. Vehicle Dynamics Control System | 9 |
| 4. VDC Control Module and Hydraulic Control Unit (VDCCM&H/U) | 10 |
| 5. ABS Sequence Control | 21 |
| 6. VDC Sequence Control | 24 |
| 7. Yaw Rate and G Sensor | 27 |
| 8. Steering Angle Sensor | 28 |
| 9. Front ABS Wheel Speed Sensor | 33 |
| 10. Rear ABS Wheel Speed Sensor | 36 |
| 11. Front Magnetic Encoder | 38 |
| 12. Rear Magnetic Encoder | 39 |
| 13. VDC OFF Switch | 40 |