

9. Stop Light System

A: WIRING DIAGRAM


Refer to "Stop Light System" in the wiring diagram. <Ref. to WI-287, WIRING DIAGRAM, Stop Light System.>

B: INSPECTION

1. CHECK STOP LIGHT SWITCH

- 1) Disconnect the stop light switch connector.
- 2) Measure the resistance between stop light switch terminals.

Preparation tool:
Circuit tester



LI-01062

| Terminal No. | Inspection conditions | Standard |
|--------------|-------------------------------|---------------|
| 2 — 3 | When brake pedal is depressed | Less than 1 Ω |
| | When brake pedal is released | 1 MΩ or more |

- 3) Replace the stop light switch if the inspection result is not within the standard value.

C: NOTE

For operation procedures of each component of the stop light system, refer to the respective section.

- Rear combination light assembly: <Ref. to LI-48, Rear Combination Light Assembly.>
- Rear finisher light assembly: <Ref. to LI-57, Rear Finisher Light Assembly.>
- Tail light/stop light bulb: <Ref. to LI-50, Tail/Stop Light Bulb.>
- High-mounted stop light: <Ref. to LI-63, High-mounted Stop Light.>