


INSPECTION

1. REMOVE CIRCUIT OPENING RELAY



2. INSPECT CIRCUIT OPENING RELAY

(a) Inspect the relay continuity.

(1) Using an ohmmeter, check that there is no continuity between terminals 1 and 2.


If there is continuity, replace the relay.

(2) Check that there is continuity between terminals 2 and 4.

If there is no continuity, replace the relay.

(3) Check that there is continuity between terminals 5 and 5.

If there is no continuity, replace the relay.




(b) Inspect the relay operation.

(1) Apply battery positive voltage across terminals 3 and 5.

(2) Using an ohmmeter, check that there is continuity between terminals 1 and 2.

If there is no continuity, replace the relay.



(3) Apply battery positive voltage across terminals 2 and 4.

(4) Using an ohmmeter, check that there is continuity between terminals 1 and 2.

If there is no continuity, replace the relay.

3. REINSTALL CIRCUIT OPENING RELAY