


DIAGNOSTICS – ENGINE (1GR-FE)

DTC No.	DTC Detecting Condition	Trouble Area
P0230	Open or short in fuel pump relay circuit	<ul style="list-style-type: none">• Open or short in fuel pump relay circuit• Fuel pump relay• Circuit opening relay• Fuel pump• ECM

WIRING DIAGRAM



HINT:


This diagnostic chart is based on premise that engine is started. If the engine is not started, proceed to problem symptoms table on [DI-33](#).

INSPECTION PROCEDURE

HINT:

Read freeze frame data using the hand-held tester. Freeze frame data records the engine conditions when a malfunction is detected. When troubleshooting, freeze frame data can help determine if the vehicle was running or stopped, if the engine was warmed up or not, if the air-fuel ratio was lean or rich, as well as other data from the time when a malfunction occurred.

1 Check voltage between terminal FPR and E1 of ECM.



CHECK:

Measure the voltage between terminals of E5 ECM connectors.

OK:


Tester Connection	Condition	Specified Condition
FPR (E5-30) – E1 (E5-1)	STA signal ON	9 to 14 V
FPR (E5-30) – E1 (E5-1)	STA signal OFF	0 to 3 V

OK

Replace ECM (See page [SF-66](#)).

NG

2 Check fuel pump relay.



PREPARATION:

Remove the fuel pump relay from the engine room R/B.

CHECK:

Inspect the fuel pump relay.

OK:

Terminal No.	Condition	Specified Condition
3 – 4	Apply B+ between terminals 1 and 2	10 kΩ or higher
3 – 4	Usually	Below 1 Ω
3 – 5	Usually	10 kΩ or higher
3 – 5	Apply B+ between terminals 1 and 2	Below 1 Ω


NG

Replace fuel pump relay.

OK

3

Check for open and short in harness and connector between fuel pump relay and ECM.



PREPARATION:

- (a) Remove the fuel pump relay from the engine room J/B.
- (b) Disconnect the E5 ECM connector.


CHECK:

Measure the resistance between wire harness side connectors.

OK:

Standard:

Tester Connection	Specified Condition
Engine Room J/B (Fuel pump relay terminal 1) – FPR (E5–30)	Below 1 Ω
Engine Room J/B (Fuel pump relay terminal 1) or FPR (E5–30) – Body ground	10 kΩ or higher



NG

Repair or replace harness or connector.

OK

Replace ECM (See page [SF-66](#)).