

Edition: JULY 2001
Revision: AUGUST 2002
Publication No. SM2E-1A33U3

NISSAN MAXIMA

MODEL A33 SERIES

QUICK REFERENCE INDEX

GENERAL INFORMATION	GI
MAINTENANCE	MA
ENGINE MECHANICAL	EM
ENGINE LUBRICATION & COOLING SYSTEMS	LC
ENGINE CONTROL SYSTEM	EC
ACCELERATOR CONTROL, FUEL & EXHAUST SYSTEMS	FE
CLUTCH	CL
MANUAL TRANSAXLE	MT
AUTOMATIC TRANSAXLE	AT
FRONT & REAR AXLE	AX
FRONT & REAR SUSPENSION	SU
BRAKE SYSTEM	BR
STEERING SYSTEM	ST
RESTRAINT SYSTEM	RS
BODY & TRIM	BT
HEATER & AIR CONDITIONER	HA
STARTING & CHARGING SYSTEM	SC
ELECTRICAL SYSTEM	EL
ALPHABETICAL INDEX	IDX

FOREWORD

This manual contains maintenance and repair procedures for the 2002 Nissan MAXIMA.

In order to assure your safety and the efficient functioning of the vehicle, this manual should be read thoroughly. It is especially important that the PRECAUTIONS in the GI section be completely understood before starting any repair task.

All information in this manual is based on the latest product information at the time of publication. The right is reserved to make changes in specifications and methods at any time without notice.

IMPORTANT SAFETY NOTICE

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.

The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately.

Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by NISSAN must first be completely satisfied that neither personal safety nor the vehicle's safety will be jeopardized by the service method selected.

NISSAN MOTOR CO., LTD.

Overseas Service Department
Tokyo, Japan



PLEASE HELP MAKE THIS SERVICE MANUAL BETTER!

Your comments are important to NISSAN and will help us to improve our Service Manuals.
Use this form to report any issues or comments you may have regarding our Service Manuals.
Please print this form and type or write your comments below. Mail or fax to:

Nissan North America, Inc.
Technical Service Information
39001 Sunrise Drive, P.O. Box 9200
Farmington Hills, MI USA 48331
FAX: (248) 488-3910

SERVICE MANUAL: Model: _____ Year: _____

PUBLICATION NO. (Please photocopy back cover): _____

VEHICLE INFORMATION VIN: _____ Production Date: _____

Please describe any issues or problems in detail:

Page number(s) _____ *Note: Please include a copy of each page, marked with your comments.*

Are the trouble diagnosis procedures logical and easy to use? (circle your answer) YES NO

If no, what page number(s)? _____ *Note: Please include a copy of each page, marked with your comments.*

Please describe the issue or problem in detail: _____

Is the organization of the manual clear and easy to follow? (circle your answer) YES NO

Please comment: _____

What information should be included in NISSAN Service Manuals to better support you in servicing or repairing customer vehicles?

DATE: _____ YOUR NAME: _____ POSITION: _____

DEALER: _____ DEALER NO.: _____ ADDRESS: _____

CITY: _____ STATE/PROV./COUNTRY: _____ ZIP/POSTAL CODE: _____

NOTES

TEST VALUE AND TEST LIMIT (GST ONLY — NOT APPLICABLE TO CONSULT-II)

The following is the information specified in Mode 6 of SAE J1979.

The test value is a parameter used to determine whether a system/circuit diagnostic test is “OK” or “NG” while being monitored by the ECM during self-diagnosis. The test limit is a reference value which is specified as the maximum or minimum value and is compared with the test value being monitored.

Items for which these data (test value and test limit) are displayed are the same as SRT code items.

These data (test value and test limit) are specified by Test ID (TID) and Component ID (CID) and can be displayed on the GST screen.

: Applicable *: Not applicable

SRT item	Self-diagnostic test item	DTC	Test value (GST display)		Test limit	Application	Unit
			TID	CID			
CATALYST	Three way catalyst function (Bank 1)	P0420	01H	01H	Max.	X	—
		P0420	02H	81H	Min.	X	—
	Three way catalyst function (Bank 2)	P0430	03H	02H	Max.	X	—
		P0430	04H	82H	Min.	X	—
EVAP SYSTEM	EVAP control system (Small leak)	P0442	05H	03H	Max.	X	—
		P1442	05H	03H	Max.	X	—
	EVAP control system purge flow monitoring	P0441	06H	83H	Min.	X	mV
		P0456	07H	03H	Max.	X	—
H02S	Heated oxygen sensor 1 (Bank 1)	P1456	07H	03H	Max.	X	—
		P1456	07H	03H	Max.	X	—
		P0133	09H	04H	Max.	X	ms
		P1143	0AH	84H	Min.	X	mV
	Heated oxygen sensor 1 (Bank 2)	P1144	0BH	04H	Max.	X	mV
		P0132	0CH	04H	Max.	X	mV
		P0134	0DH	04H	Max.	X	s
		P0153	11H	05H	Max.	X	ms
	Heated oxygen sensor 2 (Bank 1)	P1163	12H	85H	Min.	X	mV
		P1164	13H	05H	Max.	X	mV
		P0152	14H	05H	Max.	X	mV
		P0154	15H	05H	Max.	X	s
	Heated oxygen sensor 2 (Bank 2)	P0139	19H	86H	Min.	X	mV/500ms
		P1147	1AH	86H	Min.	X	mV
		P1146	1BH	06H	Max.	X	mV
		P0138	1CH	06H	Max.	X	mV
H02S HTR	Heated oxygen sensor 1 heater (Bank 1)	P0159	21H	87H	Min.	X	mV/500ms
		P1167	22H	87H	Min.	X	mV
	Heated oxygen sensor 2 heater (Bank 2)	P1166	23H	07H	Max.	X	mV
		P0158	24H	07H	Max.	X	mV
	Heated oxygen sensor 2 heater (Bank 1)	P0032	29H	08H	Max.	X	mV
		P0031	2AH	88H	Min.	X	mV
	Heated oxygen sensor 2 heater (Bank 2)	P0052	2BH	09H	Max.	X	mV
		P0051	2CH	89H	Min.	X	mV