

General Diagnostic Table

MANUAL TRANSMISSION AND DIFFERENTIAL

26.General Diagnostic Table

A: INSPECTION

1. MANUAL TRANSMISSION

Symptom	Possible cause	Corrective action
1. Gears are difficult to intermesh. NOTE: The cause for difficulty in shifting gears can be classified into two kinds: One is a defective gear shift system and the other is defective transmission. However, if the operation is heavy and engagement of the gears is difficult, a defective clutch disengagement may also be responsible. Check whether the clutch is correctly functioning, before checking the gear shift system and transmission.	(a) Worn, damaged or burred chamfer at internal spline of the sleeve and reverse driven gear (b) Gear spline wear, damage, dents (c) Worn or scratched bushings (d) Incorrect contact or wear between synchronizer ring and gear cone	Replace. Replace. Replace. Correct or replace.
2. Gear slip-out • Gear slips out when coasting on rough road. • Gear slips out during acceleration.	(a) Defective pitching stopper adjustment (b) Loose engine mounting bolts (c) Worn fork shifter, broken shifter fork rail spring (d) Worn or damaged ball bearing (e) Excessive clearance between splines of synchronizer hub and synchronizer sleeve (f) Worn tooth step of synchronizer hub (caused by slip-out of 3rd gear) (g) Worn 1st driven gear, needle bearing and race (h) Worn 2nd driven gear, needle bearing and race (i) Worn 3rd drive gear and bushing (j) Worn 4th drive gear and bushing (k) Worn 5th drive gear and bushing (l) Worn 6th drive gear and bushing (m) Worn reverse idler gear and bushing	Adjust. Tighten or replace. Replace. Replace. Replace. Replace. Replace. Replace. Replace. Replace. Replace. Replace. Replace.
3. Noise emitted from transmission NOTE: If a noise is heard when the vehicle is parked with its engine idling and if a noise ceases when the clutch is disengaged, it may be considered that the noise is coming from the transmission.	(a) Insufficient or improper lubrication (b) Worn or damaged gears and bearings NOTE: If the trouble is only wear of the gear teeth surfaces, only a high whirring noise will occur at high speeds, but if any part is broken, rhythmical clicking sounds will be heard even at low speeds.	Lubricate with specified oil or replace. Replace.

General Diagnostic Table

MANUAL TRANSMISSION AND DIFFERENTIAL

2. DIFFERENTIAL

Symptom	Possible cause	Corrective action
1. Broken differential (case, gear, bearing, etc.) NOTE: Noise will occur, and eventually the differential will not be able to operate due to broken pieces obstructing the gear revolution.	(a) Insufficient or improper oil (b) Use of vehicle under severe conditions such as excessive load and improper use of the clutch (c) Improper adjustment of taper roller bearing (d) Improper adjustment of the drive pinion and the hypoid driven gear (e) Loose hypoid driven gear tightening bolts	Disassemble the differential and replace broken components. At the same time check other components for any trouble, and replace if necessary. Readjust the preload and backlash of the bearing, and the contact surface of gear. Adjust. Adjust. Tighten.
2. Differential and hypoid gear noises Troubles of the differential and hypoid gear always appear as noise problems. Therefore noise is the first indication of trouble. However, noises from the engine, muffler, tire, exhaust gas, bearing, body, etc. are easily mistaken for the differential noise. Pay special attention to the hypoid gear noise because it is easily confused with other gear noises. There are the following four kinds of noises. <ul style="list-style-type: none">• Gear noise when driving: If noise increases as the vehicle speed increases, it may be due to insufficient gear oil, incorrect gear engagement, damaged gears, etc.• Gear noise when coasting: Damaged gears due to misadjusted bearings and incorrect shim adjustment.• Bearing noise when driving or coasting: Cracked, broken or damaged bearings• Noise mainly when turning: Noise from differential side gear, differential pinion or differential pinion shaft, etc.	(a) Insufficient oil (b) Improper adjustment of hypoid driven gear and drive pinion (c) Worn teeth of hypoid driven gear and drive pinion (d) Loose roller bearing (e) Distorted hypoid driven gear or differential case	Lubricate. Check the tooth contact. Replace as a set. Readjust the bearing preload. Readjust the backlash of the hypoid driven gear to drive pinion, and check the tooth contact. Replace.

General Diagnostic Table

MANUAL TRANSMISSION AND DIFFERENTIAL

CLUTCH SYSTEM

CL

	Page
1. General Description	2
2. Clutch Disc and Cover	13
3. Flywheel	16
4. Release Bearing and Lever	18
5. Operating Cylinder	21
6. Master Cylinder	24
7. Clutch Pipe and Hose	26
8. Clutch Fluid	28
9. Clutch Fluid Air Bleeding	29
10. Clutch Pedal	31
11. Clutch Switch	35
12. General Diagnostic Table	37