

## 13.General Diagnostic Table

### A: INSPECTION

Read the DTC or inspect and diagnose the following data in the current data display using Subaru Select Monitor.

#### 1. LAN SYSTEM

Item	Operation	Specifications		Note
		YES	NO	
Diagnostic code	DTC is not displayed when inspecting all DTCs.	DTC is not displayed.	Perform the diagnosis according to DTC.	—
Engine coolant temperature	Check the current data display of ECM, TCM and body integrated unit. Three data value are the same.	Same values	Inspect LAN system.	If engine coolant temperature sensor is not OK, inspect the sensor circuit.
R defogger SW	It turns to ON when pressing switch. (Low-speed CAN is OK)	Turns to ON.	Inspect rear defogger switch.	Rear defogger switch is connected with Low-speed CAN.
R defogger output	When switch input, it is output.	Output	Check the body integrated unit.	If not operating with output, check the rear defogger relay.
Door lock SW	When locked with door lock switch, it turns to ON.	Turns to ON.	Inspect door lock switch.	The door lock switch is connected to the Low-speed CAN.
Door lock actuator	When locked with door lock switch, it is output.	Output	Check the body integrated unit.	—

# General Diagnostic Table

## LAN SYSTEM (DIAGNOSTICS)

### 2. BODY INTEGRATED UNIT

Item	Operation	Specifications		Note
		YES	NO	
Illumination VR power supply	Operate the illumination volume, illumination light is controlled according to the change of voltage on data display.	Illumination light is controlled with changing of data.	Inspect the illumination volume.	—
Fuel level resistance	Check the fuel level resistance and fuel level resistance 2. Both resistances are same.	Same values	Inspect the body integrated unit.	Compare the input and output values of body integrated unit.
R wiper SW input	When rear wiper SW to ON, data display turns to ON.	Turns to ON.	Inspect the rear wiper switch.	—
R wiper output	When rear wiper switch to ON, output signal turns to ON.	Turns to ON.	Check the body integrated unit.	If not operate with output turned to ON, check the rear wiper motor.
Keyless Entry	Keyless entry LOCK/UNLOCK the doors.	Operate	Inspect the keyless antenna.	If the antenna is OK, replace the body integrated unit.
Brake Switch	When brake pedal is depressed, it turns to ON.	Turns to ON.	Inspect the brake switch.	—
Shift lock solenoid	The shift lock releases when depressing the brake pedal.	Released	Inspect the shift lock.	—
Body integrated unit registration function setting	Does Vehicle equipment correspond to setting values?	Correspondence	Reconfigure the values according to vehicle equipment.	—
Customize	When changing customize setting, the registration completes correctly.	Registered	Inspect the body integrated unit.	—
Manual mode	Switch the shift (UP/DOWN) on Manual mode. Indicator is changed in 1 — 2.	Change	Inspect the shift lever.	—
Function check	Each checking item operate correctly. (Except for not equipped)	Operate	Inspect for non-functional actuator.	—
Security	After locking with keyless entry system and open the door, the security system operates and the horn sounds.	Horn sounds. (Security system operates.)	Inspect the security system.	—

**WIRING SYSTEM SECTION****WIRING SYSTEM****WI**

This service manual has been prepared to provide SUBARU service personnel with the necessary information and data for the correct maintenance and repair of SUBARU vehicles.

This manual includes the procedures for maintenance, disassembling, reassembling, inspection and adjustment of components and diagnostics for guidance of experienced mechanics.

Please peruse and utilize this manual fully to ensure complete repair work for satisfying our customers by keeping their vehicle in optimum condition. When replacement of parts during repair work is needed, be sure to use SUBARU genuine parts.

All information, illustration and specifications contained in this manual are based on the latest product information available at the time of publication approval.



# WIRING SYSTEM

WI

	Page
1. Basic Diagnostic Procedure .....	3
2. Working Precautions .....	14
3. Power Supply Circuit .....	15
4. Ground Circuit .....	22
5. Engine Electrical System .....	34
6. Radiator Fan System .....	78
7. Charging System .....	80
8. Starter System .....	81
9. Remote Engine Start System .....	83
10. AT Control System .....	88
11. AT Shift Lock Control System .....	104
12. Anti-lock Brake System .....	105
13. Vehicle Dynamics Control System .....	107
14. TPM Control System .....	111
15. Air Conditioning System .....	112
16. Power Seat System .....	119
17. Airbag System .....	122
18. Seat Belt Warning System .....	126
19. Occupant Detection System .....	127
20. Seat Heater System .....	128
21. Headlight System .....	129
22. Front Fog Light System .....	132
23. Back-up Light System .....	133
24. Stop Light System .....	134
25. Clearance Light and Illumination Light System .....	135
26. Turn Signal Light and Hazard Light System .....	140
27. Interior Light System .....	142
28. Front Wiper and Washer System .....	146
29. Rear Wiper and Washer System .....	147
30. Wiper Deicer System .....	148
31. Audio System .....	149
32. Front Accessory Power Supply Socket System .....	151
33. Rear Accessory Power Supply Socket System .....	152
34. Navigation System .....	153
35. Multi-Infomation Display (MID) System .....	155
36. Horn System .....	156
37. Power Window System .....	157
38. Remote Control Mirror System .....	161
39. Rear Defogger System .....	162
40. Combination Meter System .....	163
41. Speedometer System .....	174
42. Clock System .....	175
43. Fuel Gauge System .....	177

44.	Coolant Temperature System .....	178
45.	Oil Pressure Warning Light System .....	179
46.	Parking Brake / Brake Fluid Level Warning Light System .....	180
47.	Sunroof Control System .....	181
48.	Security System .....	183
49.	Immobilizer System .....	186
50.	Keyless Entry System .....	187
51.	Cruise Control System .....	191
52.	CAN Communication System .....	197
53.	Harness Components Location .....	200
54.	Front Wiring Harness .....	202
55.	Bulkhead Wiring Harness (In Engine Compartment) .....	204
56.	Bulkhead Wiring Harness (In Compartment) .....	206
57.	Engine Wiring Harness and Transmission Cord .....	209
58.	Instrument Panel Wiring Harness .....	215
59.	Rear Wiring Harness .....	217
60.	Door Cord .....	223
61.	Rear Wiring Harness and Trunk Lid Cord .....	225
62.	Rear Wiring Harness and Rear Gate Cord .....	227