

Basic Diagnostic Procedure

POWER SEAT MEMORY SYSTEM (DIAGNOSTICS)

1. Basic Diagnostic Procedure

A: PROCEDURE

Step	Check	Yes	No
1 PERFORM CUSTOMER INTERVIEW. Using the Check List for Interview, ask the customer the condition of how the trouble occurred.	Did you interview the customer?	Go to step 2.	Interview the customer. <Ref. to PSM(diag)-3, CHECK, Check List for Interview.>
2 CHECK LAN SYSTEM. Inspect LAN system. <Ref. to LAN(diag)-2, PROCEDURE, Basic Diagnostic Procedure.>	Is there any fault?	Perform the inspection according to the diagnosis for LAN system.	Go to step 3.
3 CHECK POWER SEAT MEMORY SYSTEM. Using the Subaru Select Monitor, read DTC of power seat memory system. <Ref. to PSM(diag)-11, OPERATION, Read Diagnostic Trouble Code (DTC).>	Is DTC displayed?	Perform the diagnosis according to DTC. <Ref. to PSM(diag)-13, LIST, List of Diagnostic Trouble Code (DTC).>	Go to step 4.
4 CHECK THE LIST OF TROUBLE SYMPTOMS. Check "TROUBLE SYMPTOM" for the power seat system. <Ref. to SE-63, TROUBLE SYMPTOM, INSPECTION, Power Seat System.>	Does the symptom apply?	Perform the diagnosis according to the inspection procedures.	Currently, the system is normal. A temporary poor contact may be a possible cause. Therefore, check the harness connector.