


# VEHICLE LIFT AND SUPPORT LOCATIONS

## RIGID FRONT SUSPENSION (RFS)



**CAUTION :** Do not use the swing arm type lift and plate type lift.

**JACK POSITION** ————— ●

Front ..... Front differential carrier

Rear ..... Rear differential carrier

**CAUTION :** When jacking-up the front and rear, make sure the car is not carrying any extra weight.


**SCREW TYPE JACK POSITION** ————— ○

### SUPPORT POSITION

Safety stand ..... ■

B04712

INDEPENDENT FRONT SUSPENSION (IFS)



JACK POSITION ————— 

Front ..... Engine under cover


Rear ..... Rear differential carrier

**CAUTION :** When jacking-up the front and rear, make sure the car is not carrying any extra weight.


SCREW TYPE JACK POSITION ————— 

SUPPORT POSITION  
Safety stand ..... 

**NOTICE:** (w/ Active Height Control Suspension)  
When jacking up the vehicle with the engine running, turn off the active height control suspension with the height control switch pushed.

**INDEPENDENT FRONT SUSPENSION (IFS)  
SWING ARM TYPE LIFT**

**NOTICE:** When lifting the vehicle, place the supports correctly at the positions shown above.

**PLATE TYPE LIFT (DO NOT USE.)**

**NOTICE:** Never use the plate type lift—using it to lift up the vehicle will cause the body shape to warp.

B04209