2. Check List for Interview

A: CHECK

Inspect the following item about the vehicle's state.

1. DISPLAY OF COMMUNICATION ERROR

Communication error is displayed in odo/trip meter. (Except for meter with MID)	When and how often are they displayed? ❑ Always ❑ Sometimes ❑ Only once
	Which communication error is displayed? (Record them all) ❑ Er IU (Fail in the body integrated unit) ❑ Er HC (Fail of high-speed CAN) ❑ Er LC (Fail of low-speed CAN) ❑ Er — (Fails of both high-speed and low-speed CAN) ❑ Er EG (Fail of EGI communication data) ❑ Er TC (fail of TCM communication data) ❑ Er Ab (Fail of vehicle dynamics control (VDC)/ABS communication data)
Ignition key position	❑ OFF ❑ ACC ❑ ON (before starting engine) ❑ START ❑ ON (after starting engine, engine is running) ❑ ON (after starting engine, engine is at a standstill)
Timing	❑ Immediately after turning the ignition ON. ❑ Immediately after turning the ignition to START.

2. DISPLAY STATUS IN THE COMBINATION METER

Display status in the combination meter	a) Engine coolant temperature gauge display	❑ OK / ❑ NG
	b) Fuel gauge display	❑ OK / ❑ NG
Display of other indicators	c) Malfunction indicator light	❑ ON / ❑ OFF
	d) SPORT indicator light (AT warning light)	❑ ON / ❑ OFF
	e) ABS warning light/Vehicle dynamics control (VDC) warning light	❑ ON / ❑ OFF
	f) Security indicator light	❑ ON / ❑ Blink / ❑ OFF
	g) Seat belt warning light (Driver's seat)	❑ ON / ❑ OFF
	h) Seat belt warning light (Passenger's seat)	❑ ON / ❑ OFF

3. SYMPTOM

Vehicle condition	a) Lighting adjustment is not possible by the illumination volume control.	❑ Yes / ❑ No
	b) Rear wiper does not operate.	❑ Yes / ❑ No
	c) Wiper de-icer does not operate.	❑ Yes / ❑ No
	d) Rear defogger does not operate.	❑ Yes / ❑ No
	e) Door lock does not operate.	❑ Yes / ❑ No
	f) Trunk/rear gate lock does not operate.	❑ Yes / ❑ No
	g) Drivers door lock does not operate.	❑ Yes / ❑ No
	h) Shift lock does not operate.	❑ Yes / ❑ No
	i) Key illumination blinks.	❑ Yes / ❑ No

Check List for Interview

4. CONDITIONS UNDER WHICH TROUBLE OCCURS

Driving condition	❏ At standstill (While idling)		
	❏ When the vehicle is running	Vehicle speed km/h (MPH)	
	❏ While accelerating	Acceleration km/h (MPH) to km/h (MPH)	
	❏ Decelerating (With braking)	Deceleration km/h (MPH) to km/h (MPH)	
	❏ Decelerating (Without braking)	Deceleration km/h (MPH) to km/h (MPH)	
	❏ Flat road ❏ Uphill ❏ Downhill ❏ Gravel road ❏ Bumpy road ❏ Snowy road		
	Does it occur when operating any part? Operated part: Trouble symptom:		
	Are there any other troubles occurred? From where: Trouble symptom:		