2. Check List for Interview

A: CHECK

Inspect the following item about the vehicle's state.

1. DISPLAY OF COMMUNICATION ERROR

Communication error is	When and how often are they displayed?			
displayed in odo/trip meter.	Always			
	Only once			
	Which communication error is displayed? (Record them all)			
	Er IU (Fail in the body integrated unit)			
	Er HC (Fail of high-speed CAN)			
	Er LC (Fail of low-speed CAN)			
	Er — (Fails of both high-speed and low-speed CAN)			
	Er EG (Fail of EGI communication data)			
	Er TC (Fail of TCM communication data)			
	Er Ab (Fail of vehicle dynamics control (VDC)/ABS communication data)			
	Er bb (Fail of brake vacuum system)			
Ignition key position	OFF OFF			
· · · ·				
	ON (Before starting engine)			
	START			
	ON (After starting Engine, engine is running)			
	ON (After starting Engine, engine is at a standstill)			
Timing	Immediately after turning the ignition to ON.			
-	Immediately after turning the ignition to START.			

2. DISPLAY IN COMBINATION METER

Display in combination meter	a) Display of engine coolant temperature gauge	OK / 🗋 NG
	b) Display of fuel gauge	OK / 🗋 NG
Display of other indicators	c) Malfunction indicator light	ON / OFF
	d) SPORT indicator light (AT warning light)	ON / OFF
	e) ABS warning light/Vehicle dynamics control (VDC) warning light	ON / OFF
	f) Security indicator light	ON / DBlink / OFF
	g) Seat belt warning light (Driver's seat)	ON / OFF
	h) Seat belt warning light (Passenger's seat)	ON / OFF

3. SYMPTOMS

Behavior of vehicle	a) Illumination volume control is not available.	Yes / 🛄 No
	b) Rear wiper does not operate.	Yes / 🛄 No
	c) Wiper deicer does not operate.	Yes / 🛄 No
	d) Rear defogger does not operate.	Yes / 🛄 No
	e) Door lock does not operate.	Yes / 🛄 No
	f) Trunk/rear gate lock does not operate.	Yes / 🛄 No
	g) Driver's door lock does not operate.	Yes / 🛄 No
	h) Shift lock does not operate.	Yes / 🛄 No
	i) Key illumination blinks.	Yes / 🛄 No

4. CONDITIONS UNDER WHICH TROUBLE OCCURS

Driving condition	At standstill (While idling)		
	When the vehicle is running	Vehicle speed km/h (MPH)	
	Accelerating	Acceleration km/h (MPH) to	km/h (MPH)
	Decelerating (With braking)	Deceleration km/h (MPH) to	km/h (MPH)
	Decelerating (Without braking)	Deceleration km/h (MPH) to	km/h (MPH)
	 Flat road Uphill Downhill Gravel road Bumpy road Snowy road Does it occur when operating any page 	part?	
	Operated part: Trouble Symptom:		
	Are there any other troubles occurr From where:	red?	
	Trouble Symptom:		