

AIR INLET SERVOMOTOR INSPECTION




REMOVE BRACKET

- Disconnect the wire harness clamp.
- (b) Remove the 2 bolts and bracket.



3. REMOVE AIR INLET SERVOMOTOR


- (a) Disconnect the connector.
- (b) Remove the 3 screws and servomotor.



. INSPECT AIR INLET SERVOMOTOR OPERATION

) Connect the positive (+) lead from the battery to terminal 5 and negative (-) lead to terminal 2, then check that the arm turns to "FRESH" side smoothly.

AC25U-01




 (b) Connect the positive (+) lead from the battery to terminal 1 and negative (-) lead to terminal 5, then check that the arm turns to "RECIRC" side smoothly.

If operations are not as specified, replace the servomotor.

5. INSTALL AIR INLET SERVOMOTOR

- (a) Install the servomotor with the 3 screws.
- (b) Connect the connector.



. INSTALL BRACKET

- (a) Install the bracket with 2 bolts.
- (b) Connect the wire harness clamp.

7. INSTALL GLOVE COMPARTMENT DOOR (See page BO-104)