

D

Е

РΒ

G

Н

J

Κ

L

M

# **CONTENTS**

IOISE, VIBRATION, AND HARSHNESS (NVH)		Removal and Installation	3
ROUBLESHOOTING	2	Inspection	3
NVH Troubleshooting Chart	2	Adjustment	4
PARKING BRAKE CONTROL	3	SERVICE DATA AND SPECIFICATIONS (SDS)	5
Components	3	Parking Brake	5

PB-1

### NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

# NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING NVH Troubleshooting Chart

PFP:00003

EFS001G9

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Reference page		Refer to BR section	Refer to BR section.	Refer to BR section	Refer to BR section	I	Refer to BR section	I	I	I	Refer to BR section	Refer to FAX AND RAX section	Refer to FAX AND RAX section	Refer to FSU AND RSU section	Refer to WT section	Refer to WT section	Refer to PS section	
Possible cause and SUSPECTED PARTS		Pads - damaged	Pads - uneven wear	Shims damaged	Rotor imbalance	Rotor damage	Rotor runout	Rotor deformation	Rotor deflection	Rotor rust	Rotor thickness variation	DRIVE SHAFT	AXLE	SUSPENSION	TIRES	ROAD WHEEL	STEERING	
Symptom E		Noise	Х	Х	Х								Х	Х	Х	Х	Х	Х
	BRAKE	Shake				Х							Х	Х	Х	Х	Х	Х
		Shimmy, Judder				Х	Х	Х	Х	Х	Х	Х		Х	Х	Х	Х	Х

X: Applicable

#### PARKING BRAKE CONTROL

PFP:36010

Components

EFS001GA

Α


В

Е

РΒ

Н


M



#### **Removal and Installation**

EFS001GB

- 1. Remove center console.
- Disconnect warning lamp switch connector.
- 3. Remove cable mounting bolt. Loosen cable and remove self-locking nut.
- 4. Remove cable from toggle lever of disc brake.



Inspection

EFS001GC

 Operate parking brake lever with a force of 196 N (20 kg,44 lb). Check stroke is within specified number of notches. (Check it by hearing clicks of ratchet.)

Lever stroke : 7 - 8 notches


- Check parking lever assembly for bend, damage and cracks, and replace if necessary.
- Check cables and equalizer for wear and damage. If a malfunction is detected, replace applicable part.
- Check parking brake warning lamp switch. If a malfunction is detected, replace applicable part.
- Check each part for deformation, or damage by contact with other parts. If a malfunction is detected, replace applicable part.

**PB-3** 

#### PARKING BRAKE CONTROL

Adjustment

1. Insert a deep-well socket wrench into opening of parking brake lever. Rotate self-locking nut to fully loosen cable. Return parking brake lever and adjust rear brake shoe clearance.




- 2. Rotate road wheels to be sure that there is no drag.
- 3. After adjusting clearance of rear shoes, with no drag on rear brake, adjust cable as follows:
- Pull parking brake lever up so that a deep-well socket wrench can be inserted.
- b. Insert a deep-well socket wrench into opening of parking brake lever. Rotate self-locking nut to adjust lever stroke.

#### **CAUTION:**

Do not reuse self-locking nut after removing it.

c. Operate parking brake lever 3 to 4 times with a force of 196 N (20 kg,44 lb). Be sure lever stroke is within the specified number of notches.



d. Return parking brake lever completely. Be sure there is no drag on rear brake.

## **SERVICE DATA AND SPECIFICATIONS (SDS)**

Parking Brake						
-	Lever stroke [operating force 196 N (20 kg,44 lb)]	7 to 8 notches				
	Total stroke	18 notches				
_	Brake warning lamp stroke	Within 1 notch				

**SERVICE DATA AND SPECIFICATIONS (SDS)** 

PFP:00030 A

В

С

D

Е

РΒ

G

Н

ī

J

Κ

M

# **SERVICE DATA AND SPECIFICATIONS (SDS)**