

BODY

INSPECTION

1. TIGHTEN BOLTS AND NUTS ON CHASSIS AND BODY

(a) Where necessary, tighten all parts of the chassis.

- Front axle and suspension
- Driven train
- Rear axle and suspension
- Steering system
- Brake system
- Engine mounting etc.

(b) Where necessary, tighten all parts of the body.

- Seat belt system
- Seats
- Doors and hood
- Body mountings
- Fuel tank
- Exhaust pipe system etc.

2. CHECK TIRES AND INFLATION PRESSURE

(a) Check tires for abnormal abrasion or cracks.

(b) Check and adjust the tires inflation pressure.

Cold tire inflation pressure: (See page SA-2)

3. CHECK LIGHTS, HORNS, WIPERS AND WASHERS

Check the function of lights, horns, wipers and washers.

4. ROAD TEST

(a) Check the engine and chassis for abnormal noises.

(b) Check that the vehicle does not wander or pull to one side.

(c) Check that the brakes work properly and do not drag.

(d) Do setting of the parking brake shoes and drum.

5. FINAL INSPECTION

(a) Check the operation of the body parts:

- Hood
 - Auxiliary catch operates properly
 - Hood locks securely when closed
- Front and rear doors
 - Door locks operate properly
 - Doors close properly
- Luggage compartment door
 - Door lock operates properly
- Seat adjusts easily and locks securely in any position
 - Front seat back locks securely in any position
 - Folding-down rear seat backs lock securely

(b) Be sure to deliver a clean car. Especially check:

- Steering wheel
- Shift lever knob
- All switch knobs
- Seats