

INSTALLATION

1. INSTALL UPPER SUSPENSION ARM TO BODY

Torque: 59 N·m (600 kgf·cm, 44 ft·lbf)

HINT:

After stabilizing the suspension, torque the bolt.

2. INSTALL FRONT SHOCK ABSORBER (See page SA-19)

3. INSTALL FRONT WHEEL

Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)

4. CHECK FRONT WHEEL ALIGNMENT (See page SA-4)

5. CHECK ABS SPEED SENSOR SIGNAL

w/VSC (See page DI-318)

w/o VSC (See page DI-251)