

HOW TO PROCEED WITH TROUBLESHOOTING

HINT:

- Use this procedure to troubleshoot the power mirror control system.
- The intelligent tester should be used in steps 3 and 5.

1 VEHICLE BROUGHT TO WORKSHOP

NEXT

2 CUSTOMER PROBLEM ANALYSIS CHECK AND SYMPTOM CHECK

NEXT

3 CHECK COMMUNICATION FUNCTION OF BODY MULTIPLEX COMMUNICATION SYSTEM (BEAN)

HINT:

See page [MP-6](#)

- (a) Use the intelligent tester to check for normal function of the multiplex communication system.
- (1) (ECU unconnected, communication line malfunctioning) If no code are output, proceed to A.
 - (2) (ECU unconnected, communication line malfunctioning) If any codes are output, proceed to B.

B

GO TO MULTIPLEX COMMUNICATION SYSTEM

A

4 PROBLEM SYMPTOMS TABLE

HINT:

See page [MI-5](#)

NEXT

5 OVERALL ANALYSIS AND TROUBLESHOOTING

- (a) Data list/Active test

HINT:

See page [MI-9](#)

- (b) Circuit inspection

- (c) Terminals of ECU

HINT:

See page [MI-6](#)

NEXT

6 ADJUST, REPAIR OR REPLACE

NEXT

END