


ILLUMINATION



ILLUMINATION

SERVICE HINTS

TAILLIGHT RELAY

(1) 2 – (1) 3 : CLOSED WITH LIGHT CONTROL SW AT **TAIL** OR **HEAD** POSITION (WHEN LIGHT AUTO TURN OFF SYSTEM IS OFF)

R 7 RHEOSTAT

1–2 : APPROX. 12 VOLTS WITH RHEOSTAT FULLY TURNED COUNTERCLOCKWISE AND 0VOLTS WITH FULLY TURNED CLOCKWISE

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
A11	20	F10	19	J 2	20
A12	20	F13	20	J 3	20
A13	21	G 1	20	J 5	20
C 7	20	G 2	20	R 2	A 20
C11	20	H 9	20	R 3	B 20
C14	20	H10	20	R 5	20
C15	20	H11	20	R 7	20
D 2	20	J 1	20	T 5	20

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
1	18	R/B NO. 1 (LEFT LICK PANEL)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA3	22	COWL WIRE AND ENGINE ROOM MAIN WIRE (LEFT FENDER)
ID2	24	COWL WIRE AND FLOOR NO. 1 WIRE (LEFT KICK PANEL)
IF1	24	INSTRUMENT PANEL WIRE AND COWL WIRE (INSTRUMENT PANEL CENTER)

▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
ID	24	LEFT KICK PANEL
IE	24	RIGHT KICK PANEL

○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I 5	24	COWL WIRE	I11	24	COWL WIRE
I 7			I15	24	INSTRUMENT PANEL WIRE
I 8			I16		
I10					




J 1, J 2, J 5




(HINT:SEE PAGE 7)

J 3




(HINT:SEE PAGE 7)

R 2 (A)



R 3 (B)



R 5 BLACK



R 7

