



COWL TOP TO APRON BRACE (ASSY) REPLACEMENT

1. REMOVE COWL TOP TO APRON BRACE



2. INSTALL COWL TOP TO APRON BRACE



3. APPLYING SEALER TO THE ENGINE COMPARTMENT (See page PC-1)

4. APPLYING ANTI-RUST AGENT

- (a) After applying the top coat layer, apply the anti-rust agent to the inside of the necked section structural weld spots.