


FRONT DOOR BELT MOULDING ASSY LH

REPLACEMENT

7614D-01

HINT:

- The installation procedures are the removal procedures in reverse order.
 - Use the same procedures for the RH side and LH side.
 - The procedures listed below are for the LH side.
1. **REMOVE POWER WINDOW REGULATOR SWITCH ASSY** (See page 75-17)
 2. **REMOVE FRONT DOOR INSIDE HANDLE BEZEL LH** (See page 75-17)
 3. **REMOVE FRONT DOOR TRIM BOARD SUB-ASSY LH** (See page 75-17)
 4. **REMOVE DOOR FRAME GARNISH LH** (See page 75-17)
 5. **REMOVE OUTER REAR VIEW MIRROR ASSY LH** (See page 75-17)



6. REMOVE FRONT DOOR BELT MOULDING ASSY LH

- (a) Put protective tape under the moulding.
- (b) Remove the screw.
- (c) Using a moulding remover, pry out the moulding as shown in the illustration.

HINT:

Tape the remover tip before use.